


Installation

1



Place panels & joiners around stable to required configuration

2



Vertically saw side panel/s as required to proportion system snugly within stable

3



Saw out any odd shapes within stable into corresponding panels

4



Assemble system, applying silicone provided within joiners

5



Drill & plug holes in masonry, drilling through indents on system at required position to locate holes correctly

6



Screw fixing baton/s to wall in a position that will correctly secure end caps. Cut end caps to 'left' or 'right' as necessary

7



Make final pilot holes required (timber / fixing baton) then screw assembled system to walls and floor

8



Use adhesive - sealant provided to seal system to stable walls and floor, then allow 24 hours to fully cure